

# Work Order ID 77146

**\*77146\***

Page 1

November-25-11 3:16:50 PM

Item ID: D350-616-013

Accept

**\*N9000040100\***

Setup Start **\*NS1\***

Revision ID:

Item Name: Deck Plate and Tie Down

Stop **\*NS2\***

Start Date: 25/11/2011 Start Qty: 1.00

**\*1\***

Cust Item ID:

Required Date: 09/12/2011 Req'd Qty: 1.00

**\*1\***

Customer:

Reference:

Approvals: Process Plan: M.C.J Date: 11/11/25

Tooling:

Date:

Run Start **\*NR1\***

QC: \_\_\_\_\_

Date: \_\_\_\_\_ SPC (Y/N): \_\_\_\_\_

Date: \_\_\_\_\_

Stop **\*NR2\***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr

Revision Nbr

D350-616

E

*JS*

100

0.00

**\*100\***

DC

Document Control

Memo

Photocopy bluefile and create labels per PPP D350-616-013  
CHG002

0.00

*JB 8/12/14*

*MLJ 12-5-11*

110

Pick Kit

0.00

**\*110\***

Packaging

Packaging

Memo

0.00

*SP 11-12-02*

120

QC4- 100% Inspect kits for completeness

0.00

**\*120\***

QC

Quality Control

Memo

0.00

*8/12/14*

*Q*

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: \_\_\_\_\_ PAR #: \_\_\_\_\_ Fault Category: \_\_\_\_\_ NCR: Yes No DQA: \_\_\_\_\_ Date: \_\_\_\_\_

Resolution: \_\_\_\_\_ Disposition: \_\_\_\_\_ QA: N/C Closed: \_\_\_\_\_ Date: \_\_\_\_\_

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

**NOTE:** Date & initial all entries

**Work Order ID 77146****\*77146\***

Page 2

November-25-11 3:16:50 PM

Item ID: D350-616-013

Accept

**\*N9000040100\***Setup Start **\*NS1\***

Revision ID:

Item Name: Deck Plate and Tie Down

Stop **\*NS2\***

Start Date: 25/11/2011 Start Qty: 1.00

**\*1\***

Cust Item ID:

Required Date: 09/12/2011 Req'd Qty: 1.00

**\*1\***

Customer:

Reference:

Approvals: Process Plan: \_\_\_\_\_ Date: \_\_\_\_\_ Tooling: \_\_\_\_\_ Date: \_\_\_\_\_

Run Start **\*NR1\***

QC: \_\_\_\_\_ Date: \_\_\_\_\_ SPC (Y/N): \_\_\_\_\_ Date: \_\_\_\_\_

Stop **\*NR2\***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
130		0.00							
<b>*130*</b>									
Packaging	Memo	0.00							
Packaging	Identify and pack for shipping as per PPP D350-616-013								
	Location: _____								
	PPP Rev: <u>E</u>								
140	QC21- Final Inspection - Work Order Release	0.00							
<b>*140*</b>									
QC	Memo	0.00							
Quality Control									

PPP 81384

6/5/14

12/5/15

MF 12-05-14

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: \_\_\_\_\_ PAR #: \_\_\_\_\_ Fault Category: \_\_\_\_\_ NCR: Yes No DQA: \_\_\_\_\_ Date: \_\_\_\_\_

Resolution: \_\_\_\_\_ Disposition: \_\_\_\_\_ QA: N/C Closed: \_\_\_\_\_ Date: \_\_\_\_\_

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

**NOTE:** Date & initial all entries

# Picklist Print

November-25-11 3:16:55 PM

Page 1

Work Order ID: 77146

**\*77146\***

Parent Item: D350-616-013

**\*D350-616-013\***

Parent Item Name: Deck Plate and Tie Down

Start Date: 25/11/2011

Required Date: 09/12/2011

Start Qty: 1.00

Required Qty: 1.00

Comments: IPP A 07.05.22 coss issue EC  
IPP Rev:B 08-12-10 rev.E as per dwg DD verified by:ec

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
---------------------------------	------------------------	---------------	-------------	---------------------	------------------	-----------------	--------------------	----------------	-------------	--------------	---------------	----------------	--------

D2360		Manufactured	No				Each	0.0000					
-------	--	--------------	----	--	--	--	------	--------	--	--	--	--	--

**\*D2360\***

Litter Tie Down Assembly

D3179-041

Manufactured No

Each 1.0000

**\*D3179-041\***

Fwd Litter Tie Down

Location

Loc Qty

Loc Code

ST225

1

70581

1

D350-616-015

Manufactured No

Each 2.0000

**\*D350-616-015\***

Deck Plate

Location

Loc Qty

Loc Code

FG023

2

74706

2

*Handwritten notes and signatures:*  
78614 JB .5  
SP  
76203 JB .5  
B73179  
SP 84142 JB  
11/12-02  
12/05/11  
5

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: \_\_\_\_\_ PAR #: \_\_\_\_\_ Fault Category: \_\_\_\_\_ NCR: Yes No DQA: \_\_\_\_\_ Date: \_\_\_\_\_

Resolution: \_\_\_\_\_ Disposition: \_\_\_\_\_ QA: N/C Closed: \_\_\_\_\_ Date: \_\_\_\_\_

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

REFERENCE ONLY

QTY - 011	Qty - 013	Qty - 015	Part Number	Description
X			D350-616-011	Full Litter Kit
1	X		D350-616-013	Deck Plate and Tie Down Kit
	/ 1	X	D350-616-015	Deck Plate Kit
		1	D2344	DECK PLATE (AFT)
		4	D2348	WEAR PLATE (KEY WAY)
		1	D2353	STIFFENER
	/ 1		D2360	LITTER TIE DOWN (LOCKING)
		1	D2364	DECK PLATE (FWD)
		2	D2365	WEAR PLATE (PIP PIN)
		1	D2369-1	LOCATOR PLATE
		1	D2369-3	LOCATOR PLATE
1			D2370	LITTER ASSEMBLY
1			D2493	PATIENT STOP
	/ 1		D3179-041	LITTER TIE DOWN (NON-LOCKING)
		1	D3494-1	STUB COVER
		25	MS20426AD4-5	RIVET
		25	MS20426AD4-6	RIVET
		6	MS20426AD5-7	RIVET
		6	MS20426AD5-8	RIVET
		15	MS20601AD4W2	BLIND RIVET (or CR9162-4-2)
		30	MS20601AD4W3	BLIND RIVET (or CR9162-4-3)
		6	MS21042L3	NUT (or MS21042-3)
		6	MS24693-C273	SCREW (or MS24693-273)
		22	MS24693-C48	SCREW (or MS24693-48)
		4	MS35207-264	SCREW
		10	NAS1149D0363J	WASHER (or AN960JD10)

RELEASED  
08/11/21

CANADA  
DEPARTMENT OF TRANSPORT  
AIRCRAFT CERTIFICATION  
BRANCH  
DAO # 01-O-01

APPROVED

BY: *[Signature]*  
D. SHEPHERD (DE # 02)

DATE: 08.11.07  
CERT. NO.: SH96-10  
ISSUE NO.: 2

E	MAKE DSI 9310 STANDARD; D3179-041 REPLACES D2350	RF	08.11.07
D	ADD D3494-1 STUB COVER	MB	06.01.19
C	ADD DSI 9112/9117/9130/9236/9310	MB	06.01.10
B	ADD VIEW OF D2493 TO SHEET 9	BW	96.01.09
A	NEW ISSUE	BW	95.02.20
REV.	DESCRIPTION	BY	DATE
DESIGN	BW	DART AEROSPACE LTD HAWKESBURY, ONTARIO, CANADA	
DRAWN	RF		
CHECKED	DS	DRAWING NO.	REV. E
MFG. APPR.	N/A	D350-616	SHEET 1 OF 12
APPROVED	DS	TITLE	SCALE
DE APPR.	<i>[Signature]</i>	AS350/355 LITTER KIT INSTALLATION	NTS
DATE	08.11.07	COPYRIGHT © 1995 BY DART AEROSPACE LTD THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.	